


**Moe's**  
**Tech**  
**Tip**  
of the month



# Trick of the Trade

*Got an exhaust leak? Back fire when you let off the gas? This is sometimes caused by a leak where the exhaust pipe meets the head! You just need to replace the gasket. The other place you'll see a leak is at the J tubes where they meet the muffler. With the muffler*

*heating up and cooling down so often, it's hard to keep a good seal. Your problem is usually one of two things? One, your using a cheap muffler clamp and the problem with that is both sides of the clamp are the same size or two, your using a good German clamp and have it on backwards.*

*Save yourself some time and aggravation and buy good German clamps. The German clamp has a smaller side that faces the J tubes and the larger side that faces the muffler. You'll see, it makes a difference and you won't be exhausted about your exhaust.*